Reynolds Equipment Co. LVC INFO 8-13-01

PROCEDURE FOR DOWNLOADING AMR DATA

1. Using the “Windows” LVCHost software version 4.11, go to the Data Column, Choose “Auto Download List”.
2. Choose “File”/ “Recent List”/ select filename.
3. Go to “Run” select “Call All”.
4. The AMR session will start to call all units in the list and download all data.
5. After the AMR session is finished, close the AMR window. You can print data by following the next instructions:

1. Go to “Data” column, print “Daily” or “Monthly” Profiler data.
2. Choose the file name and click “Open”.
3. Select beginning and ending date and time.
4. Choose to “Send output to” “Console” (To view using “Notepad”) or “Printer” (To print to printer).

File: Procedure for getting AMR Data in New LVCHost.Doc